

Freedom
Heat Pumps

Model Numbers
RASM Monoblocs
RWM Splits
RWD Combi (pre-plumbed)
RWH High temp

Air Source Heat Pump Handover and Maintenance Log Book



HITACHI

Freedom Heat Pumps

Who are Freedom Heat Pumps?

Freedom Heat Pumps are a wholesale distribution company for the Samsung EHS and the Hitachi Yutaki range of heat pumps and underfloor heating systems. We offer technical support, training, design and consultancy services and operate the www.samsungehs.co.uk and www.freedomhp.co.uk web sites and freedom heat pumps and Hitachi Yutaki Facebook pages.

We launched Samsung's eco heating systems in the UK in 2010 and have been market leaders in this sector with over 5000 units out in the field. In 2016 we started distributing Hitachi's Yutaki range of units to expand our heat pump portfolio and market influence.

How we work

Our approach is very straightforward. If you have a set of plans or an outline of the requirements for a project, send them to sales@freedomhp.co.uk. From there, we will produce a heat loss calculation in line with today's standards, and put together a list of the kit required at your cost price.

Alternatively, if you don't currently have a heat pump project, but would like to become a heat pump installer, and don't know where to start, contact us on 02380 274833 or email us at sales@freedomhp.co.uk and we can set you on the correct course.

Homeowners

If you are the homeowner please ask your installer for the pdf homeowner manual or download it at www.freedomhp.co.uk. Scroll to the bottom and click the link for end user manual. It shows how the unit should be used and how to get the best from it.

Hitachi Warranty Registration 7 Year

All Hitachi heat pumps can now be registered for a 7-year parts warranty, covering only the Hitachi components. Any labour charges for replacing faulty parts are not covered. The Hitachi warranty does not cover, radiators, cylinders, UFH, valves, pumps etc. It is the role of the installer to offer a warranty to the end user covering the heating system including the heat pump. Your installer may offer you their own full parts labour and call out warranty as part of their maintenance agreement, but you need to discuss this with the installer / maintenance company. The warranty will be held by the end user at the address the unit is installed. It is important that a qualified engineer services the unit annually to maintain the warranty. It does not have to be the installer who does this, we can recommend engineers to do this if the installer does not want to do this work.

Your unit is not automatically registered for warranty, your installer needs to fill in a form Online at www.freedomhp.co.uk.

Once this is done a certificate and a maintenance book will be emailed to the applicant, please make sure you have a copy of this certificate, and proof of maintenance. Hitachi may ask for this when a warranty claim is made.

Installation Details

Your Name	<input type="text"/>
Your email address	<input type="text"/>
Outdoor model number	<input type="text"/>
Outdoor serial number	<input type="text"/>
You will find this on the side of the heat pump	
Indoor unit model number	<input type="text"/>
Date commissioned	<input type="text" value="/"/> <input type="text" value="/"/>
Name of Homeowner	<input type="text"/>
End user email address	<input type="text"/>
This is where the warranty certificate will be sent by Samsung	
Installation address	<input type="text"/>
Post code	<input type="text"/>

Installation Details

Company name	<input type="text"/>
Engineers name	<input type="text"/>
Office telephone number	<input type="text"/>
Is this your first Hitachi install?	<input type="text" value="YES"/> / <input type="text" value="NO"/>
Date commissioned	<input type="text"/>
Will you or your company be maintaining the Unit?	<input type="text" value="YES"/> / <input type="text" value="NO"/>
If No, Freedom Heat Pumps will advise of an engineer who can do this	

Install Photos

Please take at least 6 photos showing the outdoor unit, control box and cylinder cupboard

Hitachi Warranty Registration 7 Year


Heating Mode Commissioning Data

It is useful to take these measurements at commissioning and testing. They are for your own records, they are not needed to register the unit for warranty.

What type of system do you have?

Is there a Header, Buffer or Heat Exchanger installed?

Measure the following and record the data:



Flow temperature at Heat Pump Measure with pipe thermometer	<input type="text"/>	Return from Heating into header / plate	<input type="text"/>
Return temperature at Heat Pump	<input type="text"/>	Flow rate from flow meter	<input type="text"/>
Flow temp into header / plate	<input type="text"/>	Air temp at the back of the unit	<input type="text"/>
Return from header / plate	<input type="text"/>	Ambient air temperature Measure from the garden	<input type="text"/>
Flow temp out of header / plate to heating	<input type="text"/>		

Hot Water Mode Commissioning Data

You must be running the heat pump in hot water mode for this section

Hot water cylinder model No.	<input type="text"/>	Water flow temp at cylinder Measure with pipe thermometer	<input type="text"/>
Cylinder water temp at start-up Measure from the remote controller	<input type="text"/>	Water return temp at cylinder Measure with pipe thermometer	<input type="text"/>
Cylinder water temp after 30mins Measure from the remote controller	<input type="text"/>	Flow Rate Measure from the flow meter	<input type="text"/>

Handover of the System


Leave these 5 pages with the Homeowner.

[Search Freedom heat pumps, Handover video for Hitachi heat pump on YouTube](#)

Thank you for buying an Hitachi heat pump system, your Hitachi heat pump heats the house and hot water cylinder much like a normal fossil fuel boiler, however there are a couple of differences which you should take notice of.

Your installer should have provided you with a room thermostat if you have radiators or a thermostat in every room if you have under floor heating. They will tell you how to use these stats. The heat pump will run when it gets a run signal from the thermostat. It is not controlled by the Hitachi remote controller.

To turn on the heating all you need to do is turn up the thermostats, to turn it off you need to turn them down. The thermostat sends a run signal to the heat pump. Once the unit starts up it will take time to get to temperature, it is not instant. Within 10 minutes you should feel the radiators beginning to warm up



Weather compensation

The radiator temperatures will be lower than you are used to with a gas or oil boiler. To add to this, we run them in a weather compensation mode, this means that the unit measures the outside temperature and adjusts the radiator temperature to suit.

The colder it is outside the warmer the rads will be and vice versa. This function is automatic and is designed to save you money. In very cold weather the radiator will be at their hottest, they will reach 50°C, its possible to get to 80°C if you have an HT system.

Running your machine efficiently

It is very expensive to heat the house up from cold, with a heat pump the best advice is to maintain the house at as close to constant temperature as possible all the time.

Please DON'T set the room temperature too low when you leave the house, ideally drop it 2 degrees below your normal set temperature when you go out or it will take a long time and a lot of money to recover.

To switch off the heating in summer set the thermostats down to 16°C to avoid the heating starting up.

Your radiators will have thermostatic valves on them, you can adjust each room's temperature with these.

Handover of the System

General Advice

The heat pump comes with a controller which looks like this, you should not use this or press the buttons, it is used for commissioning and fault diagnosing the system.

On you tube (search for freedom heat pumps) there are videos showing how to use the controller, faults etc.

If the system goes into fault, the screen will show a number at the bottom starting with A, for example A020. The green light will go out and a red light will flash. The engineer will want to know this number when you call.

Please avoid turning the unit off at the power supply especially in cold weather. If the unit is off and the weather is very cold, it cannot protect itself and your warranty will be at risk.



Hot Water

Scroll right highlight DHW, press power to turn DHW on. Press up to set the temperature of the cylinder typically 55°C for a low temp and 70°C for a high temp unit

The unit is set up to maintain the water between 43 and 50°C all the time.


As you use the water the heat pump will constantly top up the cylinder. The hot water cylinder has priority over the heating, if the cylinder temperature falls 5 degrees below its set point the unit will automatically switch to heating the cylinder. This should take less than an hour.

Once set temperature is achieved the unit will go back to heating the house. The hot water cylinder loses almost no heat (1/3 a degree an hour) if no hot water is used.

An anti-legionella / disinfection operation will be completed at 3am every Wednesday morning. The unit will heat the cylinder with the immersion to 60°C, the hot water will be hotter on a Wednesday morning than the rest of the week.

If you don't require 24/7 hot water it is possible to time clock the hot water to reduce costs, the timer video on you tube will show you how to do this.

Handover of the System



Location	Function
1	Liquid Crystal Display Screen where controller software is displayed.
2	OK button To select the variables to be edited and to confirm the selected values.
3	Arrow Keys It helps the user to move through the menus and views.
4	Run/Stop button It works for all zones if none of the zones is selected or only for one zone when that zone is selected.
5	Menu button It shows the different configuration options of the user controller.
6	Return button To return to the previous screen.
7	Favourite button When this button is pressed, the selected favourite action (ECO/Comfort, Holiday, Simple timer or DHW boost) is directly executed.

Handover of the System

Common Icons

Icon	Name	Values	Explanation
OFF	Status for circuit 1, 2, DHW and swimming pool.		Circuit I or II is in Demand-OFF
		Circuit I or II is on Thermo-OFF	
		Circuit I or II is working between $0 < X \leq 33\%$ of the desired water outlet temperature	
		Circuit I or II is working between $33 < X \leq 66\%$ of the desired water outlet temperature	
		Circuit I or II is working between $66 < X \leq 100\%$ of the desired water outlet temperature	
	Mode		Heating
			Cooling
			Auto
	Setting Temperatures	Value	Displays the setting temperature of the circuit 1, circuit 2, DHW and swimming pool
		OFF	Circuit 1, Circuit 2, DHW or Swimming Pool are stopped by button or timer
	Alarm		Existing alarm. This icon appears with the alarm code
	Timer		Simple timer
			Weekly timer
	Derogation		When there is a derogation from the configured timer
	Installer Mode		Informs that user controller is logged on the installer mode which has special privileges
	Menu Lock		It appears when menu is blocked from a central control. When indoor communication is lost, this icon disappears
	Outdoor Temperature		The ambient temperature is indicated at the right side of this button

Handover of the System

Icons for the comprehensive view

Icon	Name	Values	Explanation
	Pump		This icon informs about pump operation. There are three available pumps on the system. Each one is numbered, and its corresponding number is displayed below to the pump icon when it is operating
	Heater step		Indicates which of the 3 possible heater steps is applied on space heating
	DHW Heater		Informs about DHW Heater operation. (If it is enabled)
	Solar		Combination with solar energy
	Compressor		Compressor enabled (For YUTAKI S, S COMBI and M)
			Compressors enabled. 1: R410A / 2: R-134a (For YUTAKI S80)
	Boiler		Auxiliary boiler is working
	Tariff		Tariff signal informs about some cost conditions of the consumption of the system
	Defrost		Defrost function is active
-	Central/Local	-	No icon means local mode
	Central/Local		Central mode (Three types of control: Water, Air or Full)
	Forced OFF		When forced off Input is configured and its signal is received, all the configured items on the comprehensive view (C1, C2, DHW, and/or SWP) are shown in OFF, with this small icon below
	Auto ON/OFF		When daily average is over auto summer switch-off temperature, circuits 1 and 2 are forced to OFF (Only if Auto ON/OFF enabled)
	Test Run		Informs about the activation of the "Test Run" function
	Anti-Legionella		Activation of the Anti-Legionella operation
	DHW boost		It activates the DHW heater for an immediate DHW operation
-	ECO/Comfort mode for circuits 1 and 2	-	No icon means Comfort mode
		ECO mode	


Maintenance Form: Year 1

The engineer should leave a copy of this form with the home owner as evidence of an annual service to keep up with the warranty.

What type of system do you have?

Is there a Header, Buffer or Heat Exchanger installed?

Measure the following and record the data:



Flow temperature at Heat Pump Measure with pipe thermometer	<input type="text"/>	Return from Heating into header / plate	<input type="text"/>
Return temperature at Heat Pump	<input type="text"/>	Flow rate from flow meter	<input type="text"/>
Flow temp into header / plate	<input type="text"/>	Air temp at the back of the unit	<input type="text"/>
Return from header / plate	<input type="text"/>	Ambient air temperature Measure from the garden	<input type="text"/>
Flow temp out of header / plate to heating	<input type="text"/>		

Hot Water Mode Commissioning Data

You must be running the heat pump in hot water mode for this section

Hot water cylinder model No.	<input type="text"/>	Water flow temp at cylinder Measure with pipe thermometer	<input type="text"/>
Cylinder water temp at start-up Measure from the remote controller	<input type="text"/>	Water return temp at cylinder Measure with pipe thermometer	<input type="text"/>
Cylinder water temp after 30mins Measure from the remote controller	<input type="text"/>	Flow Rate Measure from the flow meter	<input type="text"/>


Maintenance Form: Year 2

The engineer should leave a copy of this form with the home owner as evidence of an annual service to keep up with the warranty.

What type of system do you have?

Is there a Header, Buffer or Heat Exchanger installed?

Measure the following and record the data:



Flow temperature at Heat Pump Measure with pipe thermometer	<input type="text"/>	Return from Heating into header / plate	<input type="text"/>
Return temperature at Heat Pump	<input type="text"/>	Flow rate from flow meter	<input type="text"/>
Flow temp into header / plate	<input type="text"/>	Air temp at the back of the unit	<input type="text"/>
Return from header / plate	<input type="text"/>	Ambient air temperature Measure from the garden	<input type="text"/>
Flow temp out of header / plate to heating	<input type="text"/>		

Hot Water Mode Commissioning Data

You must be running the heat pump in hot water mode for this section

Hot water cylinder model No.	<input type="text"/>	Water flow temp at cylinder Measure with pipe thermometer	<input type="text"/>
Cylinder water temp at start-up Measure from the remote controller	<input type="text"/>	Water return temp at cylinder Measure with pipe thermometer	<input type="text"/>
Cylinder water temp after 30mins Measure from the remote controller	<input type="text"/>	Flow Rate Measure from the flow meter	<input type="text"/>

Maintenance Form: Year 3


The engineer should leave a copy of this form with the home owner as evidence of an annual service to keep up with the warranty.

What type of system do you have?

Pre-plumbed / Separate Cylinder

Is there a Header, Buffer or Heat Exchanger installed?

Measure the following and record the data:



Flow temperature at Heat Pump
Measure with pipe thermometer

Return from Heating into header / plate

Return temperature at Heat Pump

Flow rate from flow meter

Flow temp into header / plate

Air temp at the back of the unit

Return from header / plate

Ambient air temperature
Measure from the garden

Flow temp out of header / plate to heating

Hot Water Mode Commissioning Data

You must be running the heat pump in hot water mode for this section

Hot water cylinder model No.

Water flow temp at cylinder
Measure with pipe thermometer

Cylinder water temp at start-up
Measure from the remote controller

Water return temp at cylinder
Measure with pipe thermometer

Cylinder water temp after 30mins
Measure from the remote controller

Flow Rate
Measure from the flow meter

Maintenance Form: Year 4


The engineer should leave a copy of this form with the home owner as evidence of an annual service to keep up with the warranty.

What type of system do you have?

Pre-plumbed / Separate Cylinder

Is there a Header, Buffer or Heat Exchanger installed?

Measure the following and record the data:



Flow temperature at Heat Pump
Measure with pipe thermometer

Return from Heating into header / plate

Return temperature at Heat Pump

Flow rate from flow meter

Flow temp into header / plate

Air temp at the back of the unit

Return from header / plate

Ambient air temperature
Measure from the garden

Flow temp out of header / plate to heating

Hot Water Mode Commissioning Data

You must be running the heat pump in hot water mode for this section

Hot water cylinder model No.

Water flow temp at cylinder
Measure with pipe thermometer

Cylinder water temp at start-up
Measure from the remote controller

Water return temp at cylinder
Measure with pipe thermometer

Cylinder water temp after 30mins
Measure from the remote controller

Flow Rate
Measure from the flow meter

Maintenance Form: Year 5


The engineer should leave a copy of this form with the home owner as evidence of an annual service to keep up with the warranty.

What type of system do you have?

Pre-plumbed / Separate Cylinder

Is there a Header, Buffer or Heat Exchanger installed?

Measure the following and record the data:



Flow temperature at Heat Pump
Measure with pipe thermometer

Return from Heating into
header / plate

Return temperature at Heat Pump

Flow rate from flow meter

Flow temp into header / plate

Air temp at the back of the unit

Return from header / plate

Ambient air temperature
Measure from the garden

Flow temp out of header /
plate to heating

Hot Water Mode Commissioning Data

You must be running the heat pump in hot water mode for this section

Hot water cylinder model No.

Water flow temp at cylinder
Measure with pipe thermometer

Cylinder water temp at start-up
Measure from the remote controller

Water return temp at cylinder
Measure with pipe thermometer

Cylinder water temp after 30mins
Measure from the remote controller

Flow Rate
Measure from the flow meter

Maintenance Form: Year 6


The engineer should leave a copy of this form with the home owner as evidence of an annual service to keep up with the warranty.

What type of system do you have?

Pre-plumbed / Separate Cylinder

Is there a Header, Buffer or Heat Exchanger installed?

Measure the following and record the data:



Flow temperature at Heat Pump
Measure with pipe thermometer

Return from Heating into
header / plate

Return temperature at Heat Pump

Flow rate from flow meter

Flow temp into header / plate

Air temp at the back of the unit

Return from header / plate

Ambient air temperature
Measure from the garden

Flow temp out of header /
plate to heating

Hot Water Mode Commissioning Data

You must be running the heat pump in hot water mode for this section

Hot water cylinder model No.

Water flow temp at cylinder
Measure with pipe thermometer

Cylinder water temp at start-up
Measure from the remote controller

Water return temp at cylinder
Measure with pipe thermometer

Cylinder water temp after 30mins
Measure from the remote controller

Flow Rate
Measure from the flow meter

Maintenance Form: Year 7


The engineer should leave a copy of this form with the home owner as evidence of an annual service to keep up with the warranty.

What type of system do you have?

Pre-plumbed / Separate Cylinder

Is there a Header, Buffer or Heat Exchanger installed?

Measure the following and record the data:



Flow temperature at Heat Pump
Measure with pipe thermometer

Return from Heating into header / plate

Return temperature at Heat Pump

Flow rate from flow meter

Flow temp into header / plate

Air temp at the back of the unit

Return from header / plate

Ambient air temperature
Measure from the garden

Flow temp out of header / plate to heating

Hot Water Mode Commissioning Data

You must be running the heat pump in hot water mode for this section

Hot water cylinder model No.

Water flow temp at cylinder
Measure with pipe thermometer

Cylinder water temp at start-up
Measure from the remote controller

Water return temp at cylinder
Measure with pipe thermometer

Cylinder water temp after 30mins
Measure from the remote controller

Flow Rate
Measure from the flow meter

Freedom Heat Pumps Ltd

Unit 2 Warrior Park,
Eagle Close
Chandlers Ford,
Hampshire
SO53 4NF

Tel: 02380 274 833

Email: sales@freedomhp.co.uk

Copyright © 2018 Freedom Heat Pumps Ltd. All rights reserved.
Specifications and designs are subject to change without notice.
Non-metric weights and measurements are approximate. All
data were deemed correct at time of creation. All brand, product,
service names and logos are trademarks and/or registered
trademarks of their respective owners and are hereby recognized
and acknowledged.